

Kongres Container

Battery cabinet alarm setting



Overview

The alarm has three settings: Chime, Instant, and Delay. We only recommend using the Instant and Delay settings. The Instant setting will set the armed alarm off immediately upon opening the cabinet. The Delay setting will set the armed alarm off ten seconds after opening the cabinet.

Battery cabinet alarm setting

Contact Us

For catalog requests, pricing, or partnerships, please visit:
<https://drugiswiatowykongrespolakow.pl>