

## Kongres Container

# How to configure a 5kw inverter



## Overview

---

### What is a 5kw Solar System?

A 5kW solar system is an ideal solar system for residential consumers, such as homes, shops, schools, medical clinics, offices, hotels, restaurants, hostel, PG, banks, ATM, farmhouse, and more. After following the above steps, an expert electrician can install this type of solar system.

### What voltage should a solar inverter use?

Generally, we consider  $V_{mp}$  and  $I_{mp}$  during solar system commissioning. For example, FUSION 5kVA Hybrid Solar Inverter, it's double MPPT solar inverter and its input voltage range is 60-115V, 50 amps. After the solar panel mounting process, you can start wiring of solar panels. As per know in Step 2, it requires 60-115V dc input.

### How many solar panels in a 5kw Solar System?

The 5kW solar system has 10 no. of solar panels (SHARK550W Monofacial). We need to make 5 strings of 2 solar panels. You can take reference of below image: Here, you need 4 sq. mm. DC wire to extend wires solar panels to DCDB. The length of 4 sq. mm. dc wire depends on distance between solar panels and dcdb installation area.

### How to connect solar inverter to AC output?

Connecting wires already comes with solar batteries and its length is sufficient for connection. When we connect all sources of inputs (solar/grid/battery) then we start connecting the solar inverter to the AC output. Here, we use a 32 Amp. change over between solar inverter and load distribution and 6 sq. mm., 3 core AC wire.

### What battery supports in 5kW hybrid solar inverter?

There are two types of battery supports in 5kW hybrid solar inverter: Lead Acid and Lithium Battery. If you have lead acid battery, then you need 4no. of

150Ah solar batteries or if you have lithium battery, then you need 1 no. of CAML10048 lithium battery. In the case of a lead acid battery, you need a series connection among 4 batteries.

How to wire DCDB to solar inverter?

During solar wiring, you need 10 no. of wire thimbles, heat sink and lighter. After Solar Panel to DCDB Wiring, then we need to do DCDB to Solar Inverter Installation. First, we need 10 sq. mm. DC Wire pairs, wire thimbles and heat sink. The length of the dc wire depends on the distance between the dcdb and solar inverter.

## How to configure a 5kw inverter

---

## Contact Us

---

For catalog requests, pricing, or partnerships, please visit:  
<https://drugiswiatowykongrespolakow.pl>